Modification notes

New additional operations: Fill up or replace vial of perfume atomizer Replace battery for KEYLESS-GO key Replace low-temperature circuit coolant	

Service A
Service B
Extra work for: Service
Plus package
For every service (equipment specific)
at every service
Once at 3,000 km (1,900 mi)
Service 3 At every service
Service 4 every 2 years
Service 8 every 50,000 km (31,000 mi) / 3 years
Service 8 every 75,000 km (46,500 mi) / 3 years
Service 10 every 50,000 km (31,000 miles)/3 years
Service 11 every 75,000 km (46,500 mi)/3 years
Service 11 every 200,000 km (124,000 miles)/10 years
Service 12 every 75,000 km (46,500 mi) / 3 years
Service 13 every 200,000 km (124,000 miles)/10 years
Service 15 at every Service B
Service 20 once at 50,000 km (31,000 mi) / 3 years
Service 20 every 100,000 km (62,000 mi) / 5 years
Service 20 every 125,000 km (77,500 miles)/5 years



P00.20-2760-11

Customer	Order number	
VIN/license plate number	Current mileage	
Service code	Workshop code	
Remaining distance	Remaining time	
Oil type/viscosity	Completion time/date	
Service consultation performed at vehicle	Yes	No
Notes/explanations		
The following activities are hereby confirmed: - Completion of relevant service operations		

Signature

Α	В	Z		Input condition not OK:	\otimes	
Comple	eted				U	
X	\mathbf{X}	X				
-	-	•			•	
			Service reception The completely edited reception report for service on vehicle is available		0	AP00.20-P-0009Z
				i To be performed by the Service Advisor (where market- specific conditions require). The service scope is only completely performed when all acceptance items and the maintenance items listed in the service sheet have been fully processed.		
			Brake system Perform brake test and enter the result in		\bigcirc	
			the table		0	
			Vehicle exterior			AP42.00-P-4290BA
			Check exterior lights for proper operation		0	
			Check operation of headlamp range		\bigcirc	AP82.10-P-8252EW
			adjustment	Vehicles with dynamic LED headlamps or headlamp range controller on the exterior lights switch.	U	
			Check and correct the adjustment of the		\bigcirc	AP82.10-P-8250EW
			headlamps		0	AP82.10-P-8260E
				i On vehicles equipped with level control or dynamic LED headlamps, adjustment of the headlamps is to be invoiced as an additional operation.		
			Check charging cable and vehicle socket	oporation	\bigcirc	
			for mechanical damage	Model 205.047/247	Ŭ	AP54.10-P-5458B
			Vehicle interior Check function of windshield wipers and windshield washer system		0	
						AP82.30-P-8252CAA
			Check starter		Ο	
			Replace activated charcoal dust filter	Model 205.012/212		AP15.30-P-1550AA
			Replace activated charcoal dust litter			
						AP83.00-P-8384CAA
			Engine compartment Brake system: Check fluid level		0	
			Check engine compartment air flap		0	AP42.10-P-4210CAA
			Check low-temperature circuit coolant level		\bigcirc	AP20.00-P-2052B
				Engine 177	\sim	AP20.30-P-2052F
			Check all visible parts in engine compartment for damage and leaks	Engine 274, 276, 651	0	AP20.30-P-2052A
			Check visible area of poly-V belt for wear		\cap	AP00.20-P-0055C
					<u> </u>	

 \circledcirc Daimler AG, 7/24/15, G/07/15, ap00.20-p-1228ca, OVERVIEW for service sheet Model 205 (Countries with high dust levels)

		Engine 177		AP13.22-P-1352B
		Engine 274, 276, 626, 651		AP13.22-P-1352CW
	Underside of vehicle Check all visible parts of vehicle underside		\sim	
	for damage and leakage		0	
		_		AP00.20-P-0054E
		i The country-specific regulations for mobility and body shell		
		complaints apply.		
	Check condition of steering and tie rods		0	
				AP46.00-P-4651A
	Check condition of front axle and front		\bigcirc	
	axle ball joints		\cup	
	Check condition of drive shaft and flexible		\frown	AP33.10-P-3358A
	couplings		O	
			_	AP41.10-P-4152EW
	Check condition of rear axle and rear axle ball joints		0	
				AP35.20-P-3552A
	Check condition of suspension struts or		\bigcirc	
	shock absorbers and springs		\cup	
	Check tires for damage and cracking and		\sim	AP32.25-P-3255A
	enter result in table		O	
				AP40.10-P-4051EW
	Tires			
	 Plus package		~	
	Correct tire pressure and enter set tire pressure in the table		O	
				AP40.15-P-4061A
	Trunk			
	Plus package		-	
	Check spare wheel tire pressure, correct and enter set tire pressure in the table		Ο	
		Vehicles with spare tire		
				AP40.15-P-4061A
			_	
	Check TIREFIT tire sealant		Ο	
		Vehicles fitted with TIREFIT		
				AP40.10-P-4054R
		i Enter TIREFIT expiration date		
		here:		
		i Replace TIREFIT, invoice as		
		additional operation.		
			-	
	Check first aid kit		Ο	
		·····		AP68.00-P-6850EW
		i Enter first-aid bag expiration		
		date here:		
		i Replace first-aid kit, invoice as an additional operation.		
	Check luggage compartment illumination		\bigcirc	
	for proper operation		\cup	
	Engine compartment Plus package			
	Windshield washer system: Check/correct			
	fluid level			
		.		AP82.35-P-8210CAA
		i Use summer/winter cleaner as well as the mixing ratio to match		
		the ambient temperature.		
	Vehicle interior			
	 Plus package		\sim	
	Check lamps in the instrument cluster and interior illumination for proper operation		\bigcirc	
				AP54.30-P-5453CAA
	Vehicle interior For every service (equipment specific)			

Check ex factory driving aids		0
	Vehicles with ex factory driving aids	AP86.20-P-86491
Fill up or replace vial of perfume atomize	r	
	After consultation with customer With CODE P21 (Air quality package)	
Replace battery for KEYLESS-GO key		
	After consultation with customer	
	With CODE 889 (KEYLESS-GO) or with CODE 893 (KEYLESS-GO start function)	
External refueling		
For every service (equipment specific) AdBlue® tank: Fill up fluid level		
	After consultation with customer	
	With code U42 (BlueTEC (SCR)	
	diesel exhaust treatment) or with code U77 (BLUETEC (SCR) diesel exhaust treatment) or with CODE U79 (BLUETEC (SCR) Generation 3 diesel exhaust treatment)	
Engine compartment at every service		
Replace dust filter		
Underside of vehicle		AP83.00-P-83811
Once at 3,000 km (1,900 mi)		
Rear axle: Perform oil change		
	With code 471 (Mechanical locking differential) or with code 467 (Electronic locking differential) and with code P30 (AMG Performance Package)	AP35.00-P-3501CM0
Engine compartment Service 3 At every service		
Engine: Change oil and filter		
	Engine 177 Engine 274.910, engine 274.920	AP18.00-P-0101I AP18.00-P-0101CW
	except code M005 (4MATIC)	AF 18.00-F-0101CM
	Engine 274.920 with code M005 (4MATIC)	AP18.00-P-0101CWI
	Engine 276	AP18.00-P-0101CW2
	Engine 626	AP18.00-P-01018 AP18.00-P-0101CWI
Engine compartment	Engine 651	AF 10.00-2-01010WI
Service 4 every 2 years		
Brake system: Replace brake fluid		
		AP42.00-P-4280EV
Engine compartment Service 8 every 50,000 km (31,000 mi) / 3 years		
Replace air filter element		
	Engine 177	AP09.10-P-0980
Underside of vehicle	.	A 03.10-1-0300
Service 8 every 50,000 km (31,000 mi) / 3 years		
Rear axle: Perform oil change		
	With code 471 (Mechanical locking differential) or with code 467 (Electronic locking differential) and with code P30 (AMG Performance Package)	AP35.00-P-3501CM0
Engine compartment	U ,	

		Replace air filter element		
			Engine 274	
			Engine 274	AP09.10-P-0980CWG AP09.10-P-0980E
			Engine 626	AP09.10-P-0980E
			Engine 651	AP09.10-P-0980EWD
		Vehicle interior		
		Service 10 every 50,000 km (31,000 miles)/3 years		
		Panoramic sliding roof: clean and lubricate guide mechanism		
		g	With CODE 413 (Panoramic sliding sunroof)	AP77.20-P-7732CW
		Engine compartment Service 11 every 75,000 km (46,500 mi)/3 years		
	_	Replace fuel filter		
		Replace ruel liller		
			Engine 651	AP47.20-P-0780EWD
		Underside of vehicle Service 11 every 75,000 km (46,500 mi)/3 years		
	_	Replace fuel filter		
			Engine 626	AP47.20-P-0780A
		Vehicle interior		
		Service 11 every 200,000 km (124,000 miles)/10 years		
		Replace fuel filter		
			Engine 177, 274, 276	AP47.20-P-0780EW
		Engine compartment		
		Service 12 every 75,000 km (46,500 mi) / 3 years		
		Replace spark plugs		
			Engine 177	AP15.10-P-1580C
			Engine 274	AP15.10-P-1580CWF
			Engine 276	AP15.10-P-1580EW
		Underside of vehicle		
		Service 13 every 200,000 km (124,000 miles)/10 years		
		Replace main circuit coolant		
			Engine 177, 274, 276.8, 626, 651	AP20.00-P-2080CAA
		Replace low-temperature circuit coolant		
			Engine 177	AR09.41-P-6834MNA
			Engine 274, 276, 651	AR09.41-P-6834LW
		Vehicle exterior Service 15 at every Service B		
	_	Check condition and operation of trailer		\sim
		hitch		0
		-	With code 550 (Trailer hitch)	AP31.11-P-3152CW
		Underside of vehicle Service 20 once at 50,000 km (31,000 mi) / 3 years		
		Automatic transmission: Change oil and		
		filter		
			Transmission 722.930	AP27.00-P-2702W
		Underside of vehicle		
	_	Service 20 every 100,000 km (62,000 mi) / 5 years Automatic transmission: Carry out oil and		
		filter change		
		-	Transmission 724.2	AP27.00-P-2702A
		Underside of vehicle		
		Service 20 every 125,000 km (77,500 miles)/5 years Automatic transmission: Carry out oil and		
		filter change		
		, i i i i i i i i i i i i i i i i i i i	Transmission 722.9 except 722.930	AP27.00-P-2702W
			Transmission 725.0 without code	AP27.00-P-2702B
		Underside of vehicle	M005 (4MATIC)	
		Service 20 every 125,000 km (77,500 miles)/5 years		
		Automatic transmission and transfer case:		
		Perform oil and automatic transmission filter change		
			Transmission 725.0 with code M005	AP27.00-P-2702B
			(4MATIC)	

Brake values

	Left	Right
Front		
Rear		
Parking brake		

Tire condition

	Right front	Left front	Right rear	Left rear
Condition OK				
Condition NOK				

Set tire pressure in bar or psi

	Front axle	Rear axle	Spare wheel
bar/psi			